

Trigger



Trigger level decide when acquisition and display begin. When the input signal is higher than trigger level, signal is captured and display is steady.



Trick: You can force the trigger by moving the line up with the **Position** potentiometer RV2.